

JPH Kit Instructions



JPH Kit Instructions

- 1.) Install receiver bar (A) into vehicle. Secure in place using "L" shaped receiver pin.
- 2.) Attach vertical bar (B) to receiver bar using the 2 U-bolts with $\frac{1}{2}$ " lock washers and nuts. Do not tighten as you will need to adjust later.
- 3.) Slide mounting bar (C) over vertical bar. Adjust and tighten vertical bar to the tailgate. Tailgate must be in the down position as shown.
- 4.) Tighten the mounting bar securely against the tailgate using the 4 square head bolts.
- 5.) Remove the 2 – $\frac{5}{8}$ " bolts and lock washers from the base of your seeder. Using those bolts and lock washers mount your seeder to the mounting bar. Tighten bolts securely.
- 6.) Attach your brace rods (D) to the vertical bar using the $\frac{1}{2}$ " by 3" bolt. Install bolt – bolt – flat washer – 1 brace rod – through vertical – other brace rod – flat washer – lock washer – nut. Do not tighten yet.
- 7.) Loosen the clamp on the brace rods. Attach the other end of the brace rods to the base plate of your seeder. The brace rods attach to the ear on either side of your seeder using the $\frac{5}{16}$ " bolts with lock washer and nut. Tighten all nuts and bolts securely.
- 8.) It is recommended that you attach a strap (not supplied) through the loop on the vertical bar of your mounting kit to both sides of your truck bed.