


inches inches



WOLF

N° TAZZE DISTRIBUTRICI
 N° GOSETS DE DISTRIBUTION
 NR. VERTEILUNGSEIMER
 NO. DISTRIBUTING CUPS
 NO. VASOS DE DISTRIBUCION

6	→	7.9	8.7	9.8	11.0	11.4	11.8	13.0
5	→	9.8	10.6	11.8	13.0	13.8	14.6	15.4
4	→	12.2	13.4	14.6	16.1	17.3	18.1	19.3
3	→	16.1	17.7	19.7	21.7	22.8	24.4	26.0
2	→	24.4	26.4	29.1	32.3	34.3	36.6	39.0
1	→	48.4	53.2	58.3	65.0	68.9	72.8	78.0



Z

↑	↑	↑	↑	↑	↑	↑	↑
24	22	20	18	17	16	15	
B	A				C		

B

- UTILIZZARE SOLO SU TERRENI SOFFICI
- UTILISER SEULEMENT SUR DES SOLS MOELLEUX
- USE ON SOFT GROUND ONLY
- VERWENDUNG NUR BEI WEICHEN BÜDEN
- USAR SÓLO SOBRE TERRENOS SUAVES

A

- UTILIZZO DA PREFERIRE; ANCHE SU FILM PLASTICI
- UTILISATION Á PRÉFÉR; AUSSI SUR FILMS PLASTIQUES
- USE SUGGESTED, EVEN ON PLASTIC FILM
- VORZUGSVERWENDUNG AUCH AUF PLASTIKFOLIEN
- USO PREFERENTE TAMBIEEN SOBRE PÉLICULA DE PLÁSTICO

C

- UTILIZZO DA NON PREFERIRE
- UTILISATION NON-PRÉFÉRABLE
- USE NOT SUGGESTED
- UNVORZIEHBARE VERWENDUNG
- USO DE NO ELEGIR