



1. AL007 (1/4 X 3/8 Adaptor)
2. AL008 (1/4 BSP TEE)
3. AL009 (1/4 BSP ELL)
4. AL012 (Quick Coupler)
5. ST002 (10 Amp Fuse)
6. ST003 (5W 12V Globe)
7. BI027 (Adaptor)
8. MI013 or 5465 (Nozzle)
9. MI014 or 5383 (Nozzle)
10. MI029 or 4457 (Spring)

11. MI048 or 4646 (6 X 3/8" Screw)
12. ZU23 (Elbow)
13. ZU24 (Restrictor)
14. ZU25 (Elbow)
15. ZU30 (Restrictor)
16. 5398 (Shaft O-Ring)
17. 5403 (Motor O-Ring)
18. UF010 (Self Tap Screw)
19. UF076( Self Tap Screw)
20. HW023 (Diaphragm)

21. 6717 (Boot)
22. MI009 or M5320 (CDA Motor)
23. AL002 (Quick Coupler)
24. MI025 (CDA Disc)
25. AL001 (Quick Coupler)
26. ST008 (2 Pin Plug)
27. 4134/T (Red Wire)
28. 4368/T (Black Wire)
29. BI002 (CDA Feed Tube)
30. Cleaning Instruction/Soap