



① Lower Housing Assembly

Part Number	GPM	Description
	1 GPM	DEMAND OR BYPASS
LHA-7863-7F77	2 GPM	DEMAND OR BYPASS

② Valve Housing Assembly

Part Number	GPM	Description
	1 GPM / 2 GPM	DEMAND OR BYPASS

③ Upper Housing Assembly

Part Number	GPM	Description
	1 GPM / 2 GPM	THREADED W/ PRESSURE SWITCH
UHA-7880-8I77	1 GPM / 2 GPM	THREADED W/ BYPASS
	1 GPM / 2 GPM	QUICK ATTACH W/ PRESSURE SWITCH
UHA-7863-8I77	1 GPM / 2 GPM	QUICK ATTACH W/ BYPASS

④ Mounting Bolt Kit

Part Number	GPM	Description
	1 GPM / 2 GPM	4 MOUNTING BOLTS W/ WASHERS

⑤ Complete Pump Head Assembly

Part Number	GPM	Description
	1 GPM	THREADED W/ PRESSURE SWITCH
7880-8I77	1 GPM	THREADED W/ ADJUSTABLE BYPASS
	2 GPM	THREADED W/ PRESSURE SWITCH
7883-8I77	2 GPM	THREADED W/ ADJUSTABLE BYPASS
	1 GPM	QUICK ATTACH W/ PRESSURE SWITCH
7860-8I77	1 GPM	QUICK ATTACH W/ ADJUSTABLE BYPASS
	2 GPM	QUICK ATTACH W/ PRESSURE SWITCH
7863-8I77	2 GPM	QUICK ATTACH W/ ADJUSTABLE BYPASS

⑥ 12 VDC Motor

Part Number	GPM	Description
	1 GPM / 2 GPM	W/ 2 PIN CONNECTOR, NO ON/OFF SWITCH