



## COMPONENTS FOR SEED SPIDER CONTROLLER AND DRIVERS

Ref. No.	Part No.	Description
1	1413	Enclosure top with membrane
2	1404	Enclosure base w/ 1417 lead
3	1409	PC board – driver
4	1408	PC board – controller
5	1408.1	LCD display
6	1405	Seal
7	1406	Enclosure mount
8	1417	Lead (for pc boards)
9	1414	Lead (driver ports to pc board)
10	1416	Protection cap
11	1402	Power lead
12	1420	Lead (motor to driver)
	1422	2 meter extension cord (motor to driver – not shown)